

150mm Cone Vent Installation Instructions

STEP 1

Unpack the vent and ensure you have the following components:



CEILING FLANGE

VENT BODY

FIXING RING

STEP 2

Attach the fixing ring to the back of the vent body (as shown in image to the right). Secure the ceiling flange to the ceiling/plasterboard via the 4 screw holes



STEP 3

Once the fixing ring is attached the vent body can then be placed into the flange (as shown in image to the right). This completes the installation.

