


# **Product Manual**




## Item Checklist


### Included Parts:

		QTY:
1	ecoFAN™	(1)
2	Speed Controller	(1)
3	Power Supply	(1)
4	Speed Controller Fixing Screws 6Gx13mm	(2)
5	6mm Wall Plugs	(4)
6	8Gx32mm CSK Screws	(4)
7	Product Manual	(1)
8	Warranty Document	(1)

1



2



3



### Additional Parts & Tools Required (Not Supplied)

Hammer

Impact Drill & 6mm Masonry Drill Bit

Screwdriver with Phillips (P2) Bit

Marker Pen

Cable Ties

## Important Notices and Warnings

**WARNING: Do not proceed with the installation until you have read the entire instructions, including these warnings.**

### Install at your own risk

The installation of this product may be dangerous and includes the potential of personal injury or property damage. Please take care when installing this product and be mindful of risks. Please be aware of the following when installing this product.


- Installation requires the cutting and removal of bricks. This process can produce airborne debris and other hazards. To minimise risks wear personal protection equipment such as appropriate eye protection, gloves and a dust mask.
- When selecting a location for the ecoFAN™ make sure that the area is clear of services such as pipes and power cables.

### Important Notes

- The ecoFAN™ is designed for general household ventilation only. DO NOT use to exhaust hazardous or explosive materials and vapours.
- One side of the ecoFAN™ has an unguarded fan assembly. DO NOT use in locations that expose the unguarded side to areas readily accessible to people or animals.
- Always use the provided power supply and speed controller to power the fan. Failure to do so can damage the product.
- Ensure that the power supply and speed controller are not left on damp surfaces, fasten to available structure with cable ties if required.
- Only use one ecoFAN™ per speed controller and power supply.

**STEP 1**


Select appropriate position. Using the fan housing as a guide, mark out a circle/location on the wall.



**STEP 2—Option A**

Using an impact drill and 6mm drill bit. Drill holes spaced 3-4 cm around the marked perimeter.

Using a hammer carefully knock out the bricks to form a circular hole in the wall.




## Installation

### STEP 2—Option B


Remove the complete top and bottom shaded bricks.

Cut and remove the middle shaded bricks.



### STEP 3

Clear the hole of debris.




### STEP 4

Insert the ecoFANT™ into the hole. Make sure it is level and the correct way up. Mark the positions of the mounting holes.




The back of the wall grille has a mark to indicate correct orientation.



### STEP 5

Remove the unit and using a 6mm masonry bit, drill mounting holes as marked previously.




## Installation

### STEP 6


Insert supplied wall plugs into the 6mm drilled mounting holes.

Tap into hole with hammer until flush.




### STEP 7

Using the supplied screws, screw the ecoFAN™ into the wall plugs.




### STEP 1

Connect the speed controller long cable to the ecoFAN™ cable.



### STEP 2

Connect the Speed controllers short cable to the power supply cable.



### STEP 4

Using either the screws supplied or cable ties mount the speed controller and the power supply in a suitable location that prevents them from getting wet.


### STEP 5

Set the control mode.



Ensure the power supply and speed controller are not in contact with damp or wet surfaces.

## Installation—Speed Control Mode



The speed controller has 4 operating modes. These are selectable via the 4 position selector on the controller box.

To adjust use a 2mm flat screwdriver to turn the switch to the desired position. This can be done whilst the product is running.

The default starting position is **LO**.

### MODES:

**LO (Default)** - Continuous operation, low speed, low flow rate, very quiet, very low power consumption.

**MED** - Continuous operation, moderate speed, moderate flow rate.

**HI** - Continuous operation, high speed, high flow rate.

**AUTO** - This setting is not suitable for the ecoFAN™ when used as a sub-floor ventilator




If in Auto mode the ecoFAN™ will automatically adjust the fan speed dependent on temperature. It will turn off below 30°C. The fan speed will gradually ramp up through to maximum speed at 45°C.

## Convert From Exhaust to Supply Flow Direction

### STEP 1


Remove the 4 screws fixing the fan housing to the wall grille.



There are arrows on the motor housing that indicate the direction of airflow

### STEP 2

Reverse the fan housing and using the same screws mount the housing to the wall grille.




The motor cable should always be pointing downwards.

## Removing Wall grille for Painting

### STEP 1

Remove the 4 screws fixing the fan housing to the wall grille.




The plastic used for the wall grille is suitable for painting with standard spray paints without priming. The surface must be clean before painting.

### STEP 2

Paint wall grille and allow to dry.

Reattach the wall grille to the fan housing using the screws removed earlier (Step 1 in reverse).



## Technical Data

### **Material:**

Wall Grille:	Plastic (ASA)
Fan & Motor Housing:	Plastic (PP-TD20)
Fan Impeller:	Plastic (PA6-GF30)
Screws:	Stainless Steel (304)

<b>Weight:</b>	1.5 kg
----------------	--------

### **Electrical:**

#### *Power Supply*

Type:	Electronic Switching Mode
Input:	100-240VAC, 1~, 50/60Hz, 2A
Output:	24 VDC

<i>Fan Motor:</i>	Electronic Commutating (EC) motor
-------------------	-----------------------------------

Internal Voltage:	24 VDC
-------------------	--------

Protection Class:	IP54
-------------------	------

#### *Speed Control*

Type:	Temperature Sensing Electronic Variable Speed Controller
-------	--

Input Voltage:	24 VDC
----------------	--------

Fixed Speed Operation:	Three fixed speeds (LO, MED & HI), manually selectable via rotary selector switch.
------------------------	--

Automatic Variable Speed Operation:	Variable speed response relative to ambient temperature of speed controller location.
-------------------------------------	---

- Off below 30°C



- LO at 30°C

- Gradual ramp up to HI at 45°C

## Performance Data & Product Dimensions

Speed	Sound Pressure Level (SPL) $L_A$ @ $p_{sF}=0$ [dB(A)]	Max. running power consumption [W]	Flow rate $q_v$ @ $p_{sF}=0$ [ $m^3/hr$ ]
LO	32.8	4.4	280
MED	43	11.6	457
HI	53.5	30	734

NOTE—Sound pressure level measured 1m from fan inlet



## FAQ & Troubleshooting

**Q: Do I need an electrician to install the ecoFAN™?**

**A:** If you have an available power point that can be reached then no electrician is required. If a power point is unavailable then an electrician will be required to install one.

**Q: Can I wire it directly into the mains power?**

**A:** No, you must use the supplied power supply and speed controller for the ecoFAN™ to work correctly. Failure to do so may damage the product.

**Q: Can I duct the ecoFAN™?**

**A:** Yes the ecoFAN™ can be ducted in either exhaust or inlet mode by slipping 250mm diameter ducting over the lip of the motor housing and fixing with tape.

**Q: Can I paint the ecoFAN™?**

**A:** Yes, standard spray paint can be used to paint the ecoFAN™. No plastic primer is required, however the surface must be clean before paint application. Do not get any paint on the motor/fan module. The product should be disassembled to facilitate easier painting. Instructions on disassembly can be seen on page 11 of this manual.

### Troubleshooting

Problem	Possible Actions
Motor / Fan Not Running	Controller may be in AUTO Mode (It will not run at a temperature less than 30 °C when in AUTO)
	Change to LO to confirm controller is functioning correctly
	Check all connections are secure
	Check Power supply is plugged in
	Check Power Socket is turned on