

EHUFDHK1

This Heat Transfer Kit Includes:

- 1x VKO 150 In Line Fan with Lead & Plug
- 2 x Internal Cone Vent 150mm
- 1 x 6m Insulated Duct 150mm
- 1 x Duct tape
- 1x Hanging Tape

Installation Instructions:

- Select positions for intake cone vent and outlet cone vent. These should be clear of obstructions and no more than 6m apart for this kit.
- Cut the openings approximately 5mm bigger than the diameter of the flange on the back of the vent for both intake and outlet. Fix them securely in place.
- Select a location for the inline fan, ideally on a stable platform such as a beam or joist. Mount fan using bracket provided. Refer to fan instruction sheet for more information.
- Run ducting from outlet vent to fan. In this kit we supply 6m of insulated ducting, you will have to cut it appropriately depending on the intake/outlet distances. Please ensure ducting is fully extended keeping the duct as straight as possible. Secure duct using duct tape provided. If you are hanging ducting from joists please use the hanging tape provided.
- Run a length of ducting from the fan to the intake vent in the ceiling. Secure the system with duct tape.
- The fan comes with a lead and plug. If you have a powerpoint installed in the roofspace simply plug the fan in.

Please note any electrical work should be carried out by a qualified electrician

